

CL Hard Surface I

APPLICATION INSTRUCTIONS

STEP BY STEP

- Step 1:
Insert into bypasstray and print mirror imaged
- Step 2:
Print image in color to label 1 mode, mirror image
- Step 3:
Place substrate with image side face up
- Step 4:
Place imaged paper with image face down
- Step 5:
Place foam pad on top
- Step 6:
Press at 300F for 60 seconds
- Step 7:
Wait for substrate to cool and peel backing off cool.
- CL Hard Surface I: For OKI 6100 & 6150 print in Glossy mode

APPLICATION

Paper Mode:	Color to Label 1
ItemNo.:	JPCLHS1A4
Print mode:	Mirror Image
Temperature:	300F
Time:	60 seconds
Peel:	Cool
Pressure:	Heavy

All technical information and recommendations are based on tests we have conducted. Users should conduct their own tests before proceeding

NOTES

Accessories Required

Computer, Color Laser Printer, Heat Press, Foam Heat Pad, Felt pad (optional).

Printable side

The printable side (white glossy coated side) It is also the adhesive side.

Pressure Settings

Heavy Pressure is required for the image to completely adhere to the hard substrate.

Image Design

This paper works best with a full bleed image. When designing your image, ensure that you bleed your image at least 0.5 inches more than the substrate.

Peeling

Depending on the substrate you are imaging, the peel could be cool or hot. Please read instructions for substrate carefully. (see PDF instructions).

Care Instructions

After imaging, do not put in direct sunlight. Store at room temperature.

Storage

CL Hard Surface I has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity.

Recommended Fabrics

Metal
Plastic
Unisub Metals
Coated Wood (Lacquered)
Ceramic Tiles
Ceramic Mugs
Some types of Cardboard
White or Light Colored